



# User's Manual

## Digital PID Temperature Controller Process Controller

VER 1.3 2021-02




### 1 Notice



- Warning**
- An external protection device must be installed if failure of this instrument could result in damage to the instrument, equipment or injury to personnel.
- All wiring must be completed before power is turned on to prevent electric shock, fire or damage to instrument and equipment.
- This instrument must be used in accordance with the specifications to prevent fire or damage to instrument and equipment.
- This instrument is not intended for use in locations subject to flammable or explosive gases.
- Do not touch high-voltage connections such as power supply terminals, etc. to avoid electric shock.
- TAIWAN INSTRUMENT & CONTROL Co., Ltd. is not responsible if this instrument is repaired, modified or disassembled by other than factory-approved personnel. Malfunction can occur and warranty is void under these conditions.

### Caution

- This product is intended for use with industrial machines, test and measuring equipment. It is not designed for use with medical equipment and nuclear energy.
- This is a Class A instrument. In a domestic environment, this instrument may cause radio interference, in which case the user may be required to take additional measures.
- This instrument is protected from electric shock by reinforced insulation. Provide reinforced insulation between the wire for the input signal and the wires for instrument power supply, source of power and loads.
- This instrument is designed for installation in an enclosed instrumentation panel. All high-voltage connections such as power supply terminals must be enclosed in the instrumentation panel to avoid electric shock by operating personnel.
- All precautions described in this manual should be taken to avoid damage to the instrument or equipment.
- All wiring must be completed before power is turned on to prevent electric shock, instrument failure, or incorrect action.
- The power must be turned off before repairing work for input break and output failure including replacement of sensor, contactor or SSR, and all wiring must be completed before power is turned on again.
- Prevent metal fragments or lead wire scraps from falling inside instrument case to avoid electric shock, fire or malfunction.
- Please use crimp terminals suitable for M3 screws, as shown below:



- Tighten each terminal screw to the specified torque found in the manual to avoid electric shock, fire or malfunction.
- When the thermocouple wiring is extended, please use the compensation lead of the corresponding type to this thermocouple.

### 2 Basic Function Setting

#### 2.1 Change Input Type

1. PV 88.25 SV 888.0	Display after power-on.	2. PV 88.25 SV 88.22	Hold <b>SET</b> key + <b>&lt;</b> key 3 seconds, to enter LEVEL_3 upper display showing "INPT" with lower display showing current input type.
3. PV 88.25 SV 88.22	Press <b>&lt;</b> key the lower display flashes.	4. PV 88.25 SV 88.22	Press <b>&gt;</b> key and <b>&lt;</b> key to enter the intended input type.
5. PV 88.25 SV 88.22	Press <b>SET</b> key to store new value of INPT.	Modify input type needs to interchange of jumper location, and it needs to recalibration for linear input type change.	

#### 2.2 SV Setting

1. PV 88.25 SV 888.0	Display after power-on.	2. PV 88.25 SV 000.0	When <b>&lt;</b> key is pressed, the lower display flashes.
3. PV 88.25 SV 0.150	Press <b>&gt;</b> key and <b>&lt;</b> key to adjust set value.	4. PV 88.25 SV 81.50	Press <b>SET</b> key to store new value of SV.

#### 2.3 RUN/STOP Mode Selection

1. PV 88.25 SV 81.50	Display after power-on.	2. PV 88.25 SV 560P	Press <b>SET</b> key to enter parameter setup display, with "R_S" shown on the upper display.
3. PV 88.25 SV 560P	When <b>&lt;</b> key is pressed, the lower display flashes.	4. PV 88.25 SV 8FUR	Press <b>&gt;</b> key or <b>&lt;</b> key to select RUN/STOP mode.
5. PV 88.25 SV 8FUR	Press <b>SET</b> key to store new value of R_S.	When controller is in STOP mode, it disable OUTPUT and ALARM functions.	

#### 2.4 Setting PID Value Automatically(Auto-tuning)

1. PV 88.25 SV 81.50	Display after power-on.	2. PV 88.25 SV 86FF	Press <b>SET</b> key to get parameter setup display, as "OFF" will be shown on the upper display.
3. PV 88.25 SV 86FF	When <b>&lt;</b> key is pressed, the lower display flashes.	4. PV 88.25 SV 888.0	Press <b>&gt;</b> key or <b>&lt;</b> key to select auto tuning execution or not.
5. PV 88.25 SV 888.0	Press <b>SET</b> key to store new value of AT.	When auto-tuning AT LED lamp lit and start to output, through a few cycles to get new PID value with the precise control, if finished the AT LED will be lamp off.	

#### 2.5 Setting PID Value Manually

1. PV 88.25 SV 888.0	Display after power-on.	2. PV 88.25 SV 88.30	Hold <b>SET</b> key 3 seconds, then entering into LEVEL_2 upper display showing "P1", with lower display showing current P1 value.
3. PV 88.25 SV 00.30	When <b>&lt;</b> key is pressed, the lower display flashes.	4. PV 88.25 SV 050.0	Press <b>&gt;</b> key and <b>&lt;</b> key to set the intended P1 value.
5. PV 88.25 SV 850.0	Press <b>SET</b> key to store new value of P1.	By the same procedure, use the same ways to set integral time(I1) and derivative time(D1).	

#### 2.6 Controlling With ON/OFF Action

1. PV 88.25 SV 88.50	Display after power-on.	2. PV 88.25 SV 88.30	Hold <b>SET</b> key 3 seconds, then entering into LEVEL_2, as upper display shows "P1", with lower display showing current P1 value.
3. PV 88.25 SV 00.30	When <b>&lt;</b> key is pressed, the lower display flashes, upper display.	4. PV 88.25 SV 000.0	Press <b>&gt;</b> key until P1 = 0.0
5. PV 88.25 SV 86.00	Press <b>SET</b> key to store new value.	6. PV 88.25 SV 888.0	Press <b>SET</b> key to get parameter setup display, "HYS1" shown on the upper display.
7. PV 88.25 SV 88.22	When <b>&lt;</b> key is pressed, the lower display flashes.	8. PV 88.25 SV 88.10	Press <b>&gt;</b> key and <b>&lt;</b> key to set the intended HYS1 value.
9. PV 88.25 SV 88.10	Press <b>SET</b> key to store new value.	Heat mode formula: PV ≥ (SV + HYS1) → OUT1 OFF PV ≤ (SV - HYS1) → OUT1 ON Cool mode formula: PV ≥ (SV + HYS1) → OUT1 ON PV ≤ (SV - HYS1) → OUT1 OFF	

#### 2.7 Alarm Mode Setting

1. PV 88.25 SV 888.0	Display after power-on.	2. PV 88.25 SV 88.22	Hold <b>SET</b> key + <b>&lt;</b> key 3 seconds, then entering into LEVEL_3 upper display showing "INPT" with lower display showing current input type.
3. PV 88.25 SV 88.22	Press <b>SET</b> key to get parameter setup display, with "ALD1" shown on the upper display.	4. PV 88.25 SV 88.22	When <b>&lt;</b> SHIFT key is pressed, the lower display flashes.
5. PV 88.25 SV 88.22	Press <b>&gt;</b> key and <b>&lt;</b> key to set the intended ALD1 value.	6. PV 88.25 SV 88.22	Press <b>SET</b> key to store new value of ALD1.

#### 2.8 Alarm Value Setting

1. PV 88.25 SV 888.0	Display after power-on.	2. PV 88.25 SV 88.22	Press <b>SET</b> key to get parameter setup display, with "AL1H" shown on the upper display.
3. PV 88.25 SV 000.0	When <b>&lt;</b> key is pressed, the lower display flashes.	4. PV 88.25 SV 00.20	Press <b>&gt;</b> key and <b>&lt;</b> key to set the intended AL1H value.
5. PV 88.25 SV 88.20	Press <b>SET</b> key to store new value of AL1H.		


#### 2.9 Controlling With Manual Control

1. PV 88.25 SV 81.50	Display after power-on.	2. PV 88.25 SV 88.20	Press <b>SET</b> key to get parameter setup display, with "A_M" shown on the upper display.
3. PV 88.25 SV 88.20	When <b>&lt;</b> key is pressed, the lower display flashes.	4. PV 88.25 SV 00.00	Press <b>&gt;</b> key or <b>&lt;</b> key to select AUTO/MAN mode.
5. PV 88.25 SV 00.00	Press <b>SET</b> key to store new value of A_M.	6. PV 88.25 SV 84.50	Press <b>SET</b> key to get parameter setup display, with "MOUT" shown on the upper display.
7. PV 88.25 SV 04.50	When <b>&lt;</b> key is pressed, the lower display flashes.	8. PV 88.25 SV 100.0	Press <b>&gt;</b> key and <b>&lt;</b> key to set the intended MOUT value.
9. PV 88.25 SV 100.0	Press <b>SET</b> key to store new value of MOUT.	In manual mode and MOUT=100.0, output=100.0% continuously. In manual mode and MOUT=20.0, output=20.0% continuously.	

### 3 Flow Chart Of Parameter Setting

#### 3.1 Parameter Structure


The NFY controller is an original dual-loop controller. The parameter group of Level 1~Level 4 is of LOOP type. There are two copies kept in LOOP1 and LOOP2. Level 5 parameter group non-LOOP type is of an independent, linked with Level 4 of LOOP1 or LOOP2, as the parameter structure is shown in the diagram below.



#### 3.2 Level Operation Mode

- LEVEL 1 enter to the LEVEL 2**  
Hold SET key for 3 seconds then entering into LEVEL 2
- LEVEL 1 enter to the LEVEL 3**  
Hold SET key + SHIFT key for 3 seconds then entering into LEVEL 3
- LEVEL 2 return to the LEVEL 1**  
Hold SET key for 3 seconds then return to LEVEL 1
- LEVEL 2 enter to the LEVEL 3**  
Hold SET key for 3 seconds then return to LEVEL 3
- LEVEL 1 enter to the LEVEL 4**  
Hold SET key for 3 seconds then entering into LEVEL 2, in LEVEL 2 press SET key to find parameter "LOCK", modify LOCK value from current value to 1111 then hold SET key + SHIFT key for 3 seconds then entering into LEVEL 4
- LEVEL 2 enter to the LEVEL 5**  
Hold SET key for 3 seconds then entering into LEVEL 2, in LEVEL 2 press SET key to find parameter "LOCK", modify LOCK value from current value to 1000 then hold SET key + SHIFT key for 3 seconds then entering into LEVEL 5
- LEVEL 3 return to the LEVEL 1**  
hold SET key + SHIFT key for 3 seconds then return to LEVEL 1
- LEVEL 3 return to the LEVEL 2**  
Hold SET key for 3 seconds then return to LEVEL 2
- LEVEL 4 return to the LEVEL 1**  
Hold SET key + SHIFT key for 3 seconds then return to LEVEL 1
- LEVEL 4 return to the LEVEL 2**  
Hold SET key for 3 seconds then return to LEVEL 2
- LEVEL 5 return to the LEVEL 1**  
Hold SET key + SHIFT key for 3 seconds then entering into LEVEL 1
- LEVEL 5 return to the LEVEL 2**  
Hold SET key for 3 seconds then return to LEVEL 2

#### 3.3 Level Operation Diagram



※ : If no key is pressed within 60 seconds, it will automatically return to LEVEL 1 (user level) and display PV/SV.


#### 3.4 Data Lock Function

LOCK provides a parameter protection function to prevent the operator from touching or modifying important parameters. Conversely, when the parameter cannot be modified, please check that the set value of LCK.

LOCK	LEVEL					Descriptions
	Level_1 USER Level	Level_2 PID Level	Level_3 INPUT Level	Level_4 SET Level	Level_5 QC Level	
0000	⊙	⊙	⊙	X	X	All parameters of Level 1, 2 & 3 are able to be modified (Factory default setting)
1111	⊙	⊙	X	⊙	X	All parameters of Level 1, 2 & 4 are able to be modified
1000	⊙	⊙	X	X	⊙	All parameters of Level 1, 2 & 5 are able to be modified
0001	⊙	⊙	X	X	X	Only SV, LOOP, R_S, A_M, LOCK can be modified
0101	⊙	⊙	X	X	X	Only LOCK can be modified
0110	⊙	⊙	X	X	X	Only parameters of Level 1 and LOCK can be modified
Other	⊙	⊙	⊙	X	X	Once jumping to other levels, LOCK will be automatically restored to 0000


⊙ : allow X : inhibit

#### 3.5 Level 1 (User Level) All Parameters Display



※ If no key is pressed within 60 seconds, it will automatically return to LEVEL 1 (user level) and display PV/SV.

#### 3.6 Level 2 (PID Level) All Parameters Display



※ If no key is pressed within 60 seconds, it will automatically return to LEVEL 1 (user level) and display PV/SV.

